

Supplementary information for the MP3SA-KTS adapter For the Technovision MP3SA player

The 8 terminals on the MP3SA-KTS are wired to the first four rows and columns on the keypad port of the MP3SA.

Pin on connector	Wire Colour	Description	Terminal
2	BROWN	COL 0	1
1	RED	COL 1	2
4	ORANGE	COL 2	3
3	YELLOW	COL 3	4
10	GREEN	ROW 0	5
9	BLUE	ROW 1	6
12	WHITE	ROW 2	7
11	BLACK	ROW 3	8

For example, a button wired to the BROWN and GREEN terminals would be column 0 and row 0 (KEY 00). In the CONFIG.TXT file you would then define the function of this button. A button wired to the RED and GREEN terminal would be column 1 and row 0 (KEY 10)

Examples:

key 00 song1	will play song 1 when connecting the BROWN and GREEN terminals.
key 10 song2	will play song 2 when connecting the RED and GREEN terminals.
key 21 play	will put the MP3SA into PLAY when the ORANGE and BLUE terminals are contacted.

Other KEY functions:

pause	stop	play
next (track)*	prev (song)	disc+
disc-	songXX	discXX
replay (song)	track1	last (song)
ff	rew	vol+
vol-	max (vol)	min (vol)
mute	mute2 (toggle)	brup
brdn	brsel	brtoggle
repeat (cycle)	reset	

*text within brackets are for descriptive purpose only.

For more information contact: Technovision Interactive at (905) 420-5153