The DV01 is a multifunction digital media player that is capable of playing MPEG2, MPEG4, MP3 and JPG files. The player default (*) settings are the ones that are most often used, but you are capable of changing some of the functions within the player. To access all the choices on the SETUP menu, stop the player and then press the SETUP button on the remote.

The STANDARD OUTPUT IS VGA - press PC/AV on the remote to change the output to VIDEO.

```
PHOTO
                                                   SLIDESHOW SETUP
      THUMBNAIL DIGEST
                                                      SLIDESHOW MODE
            ON *
                                                          MANUAL
            OFF
                                                          AUTO *
      TRANSITION MODE
                                                      FOLDER REPEAT
            FAST *
                                                          ON *
            SLOW
                                                          ਬਚਨ
      ORIENTATION
                                                      INTERVAL TIME
            DEFAULT *
                                                          1 SECOND
                                                          3 SECOND *
            TGNORE
      DIGEST STYLE
                                                          5 SECONDS
            2X2
                                                          10 SECONDS
            3X3 *
                                                      TRANSITION
            4X4
                                                          FULL SCREEN *
            5X5
                                                          TOP->BOTTOM
      MAIN PAGE
                                                          BOTTOM->TOP
                                                          T/B->CENTER
MUSIC SETUP
                                                          CENTER->T/B
      REPEAT MODE
                                                          BLINDS: T->B
                                                          LEFT->RIGHT
            ONE (N/A)
            OFF (N/A)
                                                          RIGHT->LEFT
            ALL *
                                                          L/R->CENTER
      MAIN PAGE
                                                          CENTER->L/R
                                                          IMPLODE
MOVIE SETUP
                                                          BLINDS: L->R
      REPEAT MODE
                                                          CROSSFADE
                                                          RANDOM
            SINGLE (N/A)
            ONE LOOP (N/A)
                                                      AUTOSTART
            CONTINUOUS *
                                                          ON *
      DIGEST STYLE
                                                          OFF
            2X2
                                                      MAIN PAGE
            3X3 *
                                                  PREFERENCES
            4X4
            5X5
                                                      TV TYPE (VIDEO ONLY)
      SUBTITLE
                                                          MULTI
            ENGLISH *
                                                          NTSC *
                                                      PAL
            ___
                                                      TV DISPLAY (NORMAL 4:3 or WIDE 16:9)
      MAIN PAGE
                                                          NORMAL/PS (16:9 in PAN SCAN) *
                                                          NORMAL/LB (16:9 in LETTERBOX)
                                                          WIDE (4:3 STRETCHED)
                                                      VIDEO OUTPUT
                                                          S-VIDEO CVBS
                                                          VGA **
                                                      OSD LANG
                                                          ENGLISH *
                                                      OSD MESSAGE
                                                          ON
                                                          OFF *
                                                      SETUP VALUES
                                                          DEFAULT
                                                      MAIN PAGE
```

TECHNOVISION DV01 SETUP SCREEN

IR Remote Button Functions:

PC/AV: Changes the output between VGA (PC) and VIDEO (AV).

DISPLAY: Display the running time as well as the file info of the

file currently playing.

PHOTO: Displays all the .JPG files in the digest style (3x3 etc).

MUSIC: Lists all the .MP3 files.

VIDEO: Displays all the video files in the digest style (3x3 etc). FILE: Will list all the compatible files on the CF card. You can

then use the navigation buttons to preview them.

DV-01 Specifications:

PHOTO:

JPEG (.jpg, .jpeg)

Supports photo resolution up to 5120 x 3840

Output resolution: VGA 640x480

MUSIC:

MP3 (.mp3) from 32K to 256K bps

PCM wave (.wav)

VIDEO:

MPEG1 (.mpg, .dat)

MPEG2 (.mpg, .avi) will play video portion of .ob (no AC3 decoding)

MPEG4 SP, ASP (.avi, .asf, .divx) * SP is simple profile, ASP is

Advanced SP

Motion-JPEG (.avi)

VIDEO OUTPUT:

NTSC 640x480 or PAL 720x576