Operation

The TV-66K allows for button access to tracks on various digital players, including the DV-66.

- Make sure the TV-66K is not installed against a conductive surface.
- Make sure the power to the player is OFF before attaching the TV-66K.
- Attach all optional buttons to the TV-66K (see instructions below).
- Attach the supplied cable to the player and connector TS1 on the TV-66K controller.

9 Button Option (DIP 1 ON, 2 ON, 4=lockout)

With all the switches in the ON position (**factory default**) up to nine buttons can be attached directly to the terminal connectors (#1...#9) on the TV-66K with terminal 10 being the common GROUND.

Track#	Terminal connectors
1	1 and 10
2	2 and 10
3	3 and 10
4	4 and 10
5	5 and 10
6	6 and 10
7	7 and 10
8	8 and 10
9	9 and 10

Once chosen, another button cannot be chosen again for 1 second (11 seconds if DIP 4 is set to OFF). Dry contact closures must be maintained for a minimum of 60ms.

25 Button Option (DIP 1 OFF, 2 ON)

Up to 25 buttons can be attached directly to the terminal connectors in a 5x5 matrix:

. . .

Terminal Connector									
	6	7	8	9	10				
1	1	2	3	4	5				
2	6	7	8	9	10				
3	11	12	13	14	15				
4	16	17	18	19	20				
5	21	22	23	24	25				

For example: Connecting terminals 3 and 9 will send the track 14 command.

KEY34 Option (DIP 1 ON, 2 OFF)

A Technovision **KEY34** telephone keypad can be attached to the TV66K. This allows you to enter a two-digit track number (1 to 99) through the keypad.

TV66K TERMI NALS

10	9	8	7	6	5	4
\downarrow						
S2	S1	S0	R3	R2	R1	RO
CON	INECT	OR ON	THE	BACK	OF THE	KEY34

MEM5 option (DIP 1 and 2 OFF)

To attach a MEM5 membrane keypad, align the black marking on the blue membrane connector to PIN 1 on JP1 (TV66K keypad header). The five buttons, from top to bottom) will transmit the tracks 1 to 5 commands when pressed.

Technovision Inc.

TV-66K

Quick Reference Guide Version 1.41

Revision 07/11

Technovision I nc. 1845 Sandstone Manor, #2 Pickering, Ontario L1W 3X9 P:(905) 420-5153 F:(905) 420-0753 www.technovision.com

Available Options:

TV66KMC metal case 54-0000-41 and various other pushbuttons BV302 Motion Sensors MEM5 5-button membrane keypad